

torqit

# MULTIMAP SWITCHING

Part# MMP41

## Activate the Full Potential of Toyota with our ECU Multimap Switching

ECU multimap switching offers unparalleled performance and versatility by enabling you to toggle between four preset driving modes with ease. This advanced feature, integrated with your vehicle's cruise control, enhances driving dynamics for any scenario—from fuel-saving commutes to towing heavy loads.

### What Is Multimap Switching?

Our cutting-edge multimap software operates alongside your vehicle's ECU, allowing multiple performance maps to be saved directly within the ECU. Switching between these maps is simple; just use the cruise control and brake for seamless transitions. Unlike traditional remapping, multimap switching requires no additional hardware or reflashing of the ECU to change tunes.

### Now Available for:

All 70 Series & 200 Series LandCruisers (factory DPF models).

### Key Benefits:

**Adaptability** Maximise engine performance across multiple driving conditions.

**Convenience and Flexibility** Easily switch between modes without additional tools or devices.

**Enhanced Security** Immobiliser mode ensures peace of mind.

**Seamless Integration** Operates through existing vehicle systems without visible modifications.

### Applications:

- Ideal for off-road enthusiasts seeking versatility.
- Perfect for towing professionals needing dependable torque.
- Great for daily drivers looking to save on fuel.
- Excellent for anyone prioritising vehicle security.



### Standard Features ▼

#### SWITCHING VIA CRUISE CONTROL

Intuitive map selection through your vehicle's cruise control.

#### NO ADDITIONAL HARDWARE

Keeps your dashboard clean and makes reverting to the stock configuration effortless.

#### FOUR TUNE OPTIONS

Multiple driving modes to suit various needs.

##### 1 Immobiliser Mode

The ultimate security feature: your vehicle will crank but won't start, preventing theft even if keys are stolen.

##### 2 Economy Mode

Optimised for fuel efficiency, ideal for everyday driving and cost savings.

##### 3 Towing Mode

Provides robust low-end torque for reliable towing under heavy loads.

##### 4 Performance Mode

Delivers maximum power and responsiveness for a thrilling driving experience.

#### INSTANTANEOUS MAP-SWITCHING

Switch modes instantly without the hassle of reprogramming.

#### MODULEMAP DEVICE COMPATIBILITY

Retain the ability to reload your vehicle's stock file and remove the multimap file when needed.

Learn more or add this powerful feature to your vehicle, contact [sales@torqit.com.au](mailto:sales@torqit.com.au)